

Használati útmutató

**dyras**

Ébresztőóra

Modell: ALCL-002WH



---

**Kérjük, használat előtt figyelmesen olvassa el a  
használati útmutatót!**

# BIZTONSÁGI TUDNIVALÓK

Kérjük, használatba vétel előtt gondosan tanulmányozza át, és kövesse ezt a kezelési útmutatót. A készülék működtetése során az alábbiakban felsorolt biztonsági intézkedéseket feltétlenül be kell tartani.

- Ezt a készüléket nem szánták csökkent fizikai, érzékelési vagy szellemi képességű, illetve tapasztalattal vagy ismerettel nem rendelkező személyek általi használatra (beleértve a gyermekeket is), kivéve, ha egy olyan személy felügyeli vagy tájékoztatja őket a készülék használatát illetően, aki egyben felelős a biztonságukért is. Gyermekek esetében ajánlatos a felügyelet, azért, hogy biztosítsák, hogy a gyermekek ne játszanak a készülékkel. 14 éves kor alatti gyermekek a terméket nem használhatják még felügyelet mellett sem!
- A gyártó által a készülékhez nem mellékelte vagy nem javasolt eszközök, kiegészítők használata nem megengedett. Ezek alkalmazása balesetet vagy rendellenes működést okozhat.
- Ne helyezze a készüléket forró tárgyak közelébe (pl. tűzhely, fűtőtest stb.), vagy meleg felületre, illetve olyan helyre, ahonnan legurulhat, leeshet, vagy ahonnan lerántható, leverhető egy véletlen mozdulattal.
- Ne használja a készüléket robbanékony vagy gyúlékony gázok, gőzök vagy folyadékok jelenlétében.
- A készülék csak az itt leírt háztartási használatra szolgál, minden egyéb (iparszerű) felhasználás tilos!
- A készüléket vízbe vagy más folyadékba meríteni tilos! Ha a készülék belsejébe nedvesség kerül, az meghibásodást okozhat, ezért ne használja olyan helyen, ahol a levegő páratartalma magas!
- Lemerült elemet ne hagyjon a készülékben állni, azt mindig vegye ki a készülékből!

## FUNKCIÓK

- 4 számjegyű LED kijelző, 2 kijelző mód:
  - Dp-1: idő/dátum/hőmérséklet kijelzése
  - Dp-2: állandó idő kijelzés
- Idő kijelző funkció
- Dátum funkció
- Hőmérséklet funkció
- Hangvezérlés mód: normál kijelző módban nyomja meg a Down gombot a beállításhoz. „--SD” jelenti a hangvezérlés funkció kikapcsolását és a kijelző mindig bekapcsolt állapotban marad. Az „ON SD” feliratnál a hangvezérlés bekapcsolt állapotban van. Miután bekapcsolta a hangvezérlés módot, a kijelző néhány másodperc után kikapcsol és energiatakarékos módba áll. A kijelző felébresztéséhez tapsoljon a készülék közelében minimum 60 decibellel.
- Ébresztés funkció
- Fényerő beállítás: Az óra normál megjelenítési állapotában nyomja meg 3 másodpercig az UP gombot, így belép a fényerő beállításához. Nyomja meg az Up/Down gombokat a fényerő állításához (L0-tól L3-ig).

# MŰKÖDÉSI ÚTMUTATÓ

Kapcsolja be a készüléket és a LED kijelző 2 másodperc után bekapcsol. Az alapértelmezett rendszer: 24 órás formátum.

## **A dátum beállítása**

Miután belépett a beállításokba, állítsa be az évet, hónapot majd napot az Up (Fel)/Down (Le) gombok segítségével. Minden beállított elem után nyomja meg a Set gombot a továbblépéshez.

## **Az időformátum beállítása**

Miután beállította a dátumot, nyomja meg a Set gombot a 12/24 órás formátum beállításához, majd állítsa be a kívánt formátumot az Up/Down gombok segítségével. A 12 órás formátumban megjelenik a kijelzőn a PM felirat.

## **Az idő beállítása**

Az időformátum beállítása után nyomja meg a Set gombot a pontos idő beállításához. Amikor a számok villognak, nyomja meg az Up/Down gombot az óra, majd a perc beállításához. Az óra beállítása után nyomja meg a Set gombot a perc beállításához.

## **Az ébresztő beállítása**

Az idő beállítása után nyomja meg a Set gombot az ébresztés beállításához. Nyomja meg az Up/Down gombokat az ébresztés be/kikapcsolásához. „--A1” jelzi az 1. ébresztés kikapcsolását, „on:A1” jelenik meg az 1. ébresztő bekapcsolásakor. Nyomja meg a Set gombot az idő beállításához. Ugyanezekkel a lépésekkel tudja a 2. és 3. csoportot is beállítani.

## **Az ébresztési periódus beállítása**

Az ébresztő beállítása után nyomja meg a Set gombot a hétfégen való ébresztéshez. Az „ON:E” feliratnál csak hétköznap ébreszt; az „-:E” feliratnál minden nap ébreszt. Használja az Up/Down gombokat a váltáshoz.

## FIGYELEM

Kerülje az ébresztőóra leejtését vagy megütését.

Ha szükséges, tiszta, száraz ruhával törölje le a felületét!

Ne mossa le az órát vízzel, mert az óra szerkezete megsérülhet, ha vízbe meríti!

## MŰSZAKI ADATOK

Modell: ALCL-002B

- Feszültség: DC 5V
- Tápellátás: 4xAAA

## HULLADÉKKEZELÉS

### Használt elektromos és elektronikus berendezések megsemmisítése



Ez a jelzés a terméken és a csomagoláson azt jelzi, hogy tilos háztartási hulladék közé dobni a már nem használt terméket mivel kifejezetten környezetszennyező. További részletekkel kapcsolatban érdeklődjön a helyi hatóságnál.  
Ez a jelzés az Európai Unió teljes területére érvényes. Amennyiben az Európai Unión kívül szeretné megsemmisíteni a terméket érdeklődjön az ezzel kapcsolatos szabályzásokról a helyi hatóságnál.

Gyártó/Importőr: Vöröskő Kft., 8200 Veszprém, Pápai út 36.

## A CE SZIMBÓLUM



A CE jelölés azt hivatott jelezni, hogy a termék a rá vonatkozó európai uniós előírásoknak megfelel és szabadon forgalmazható az Európai Unió területén.

## Instruction manual

# **dyras**

**Alarm Clock**

**Model: ALCL-002WH**



---

**Before using this device, please read the instruction manual carefully.**

## **IMPORTANT SAFETY INFORMATION**

Please read the user manual thoroughly before using your new appliance. You must obey the safety instructions that follow when using the appliance.

- This device is not supposed to be used by physically or mentally handicapped people, or persons without experience or knowledge (including children), unless their use of the device is supervised or guided by someone who is at the same time responsible for their safety. As for children, supervision is recommended to make sure that they do not play with the device. This device is not supposed to be used by children under the age of 14, not even with supervision!
- Never use an appliance or accessory that the manufacturer did not supply with, or propose for use with, the appliance. The use of such appliances or accessories might lead to accidents or irregular function.
- Do not place the appliance near hot objects (e.g., electric or gas cooker, hob, radiator, etc.) or on a hot surface and do not use the appliance on an unstable surface, or a high surface, or any surface where it is unstable and can be knocked down in an accident.
- Do not use the appliance in the presence of explosive or inflammable gases, vapours or liquids.
- This device is intended only for household use. Do not use for industrial or retail purposes.
- Do not immerse the appliance in water or any other liquid! If humidity gets into the appliance, it can cause defects, so do not use it in the bathroom or any other room where there is high humidity.
- Always remove the battery when it stops working. Never leave a dead ("flat") battery in the appliance.

## FUNCTION INTRODUCTION

- 4-digit LED display, 2 display modes:
  - Dp-1: time/date/temperature rotation display
  - Dp-2: fixed time display
- Time display function
- Date function
- Temperature function
- Sound control mode: In the normal display state, press the DOWN button to set, "--SD" means turn off the voice control, and the display is always on; "ON SD" means turn on the voice control. After turning on the voice control mode for a few seconds, the display will automatically turn off and enter the energy-saving mode. When the close distance is greater than 60 decibels clap your hands or tap the product to wake up the display.
- Alarm clock function
- Brightness adjustment: Under the normal display state of the clock, the long press UP key enters the brightness setting for three seconds, and the short press up key (UP) key / down key (DOWN) adjusts the brightness (from L0 to L3).



## **OPERATING INSTRUCTION**

Long press the set key (until the digital flashing screen appears) to enter the setting item. The setting sequence is as follows:

### **Setting the date**

After entering setting mode, set year – month – day according to the position of digital flash, adjust up (UP)/down (DOWN) in turn.

### **Setting the time system**

After setting the date, press the set key to enter the 12/24-hour setting and press up/down to switch. In the 12-hour system, the PM light is on.

### **Setting the time**

After setting the time system, press the set key to enter the time setting. When the number is flashing, press up/down to adjust and long press fast forward/fast backward.

### **Setting the alarm**

After setting the time, press the set key to enter the alarm setting. Press up/down to set the alarm on or off. "--:A1" is off for group 1 alarm; "on:A1 is on for group 1 alarm. Press the set key again to set the alarm time. When the number is flashing, press up/down to adjust, long press fast forward or fast backward. According to this step, the second group (A2) and the third group (A3) alarm are set.

## **ATTENTION**

Avoid dropping or hitting the clock.

Wipe clock surface with a clean dry cloth if need clean.

Do not wash the clock with water, the clock mechanism can be damaged if immersed in water.

## SPECIFICATIONS

Model: ALCL-002WH

- Voltage: DC 5V
- Battery: 4xAAA

## WASTE MANAGEMENT

### Correct Disposal of this product



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Manufacturer/Importer: Vöröskő Kft., 8200 Veszprém, Pápai út 36.

## THE CE SYMBOL



The CE mark is intended to indicate that the product complies with the relevant European Union standards and can be freely marketed in the European Union.

# ***dyras***

[www.dyras.hu](http://www.dyras.hu)

Copyright © 2023 The dyras wwe.factory LLC U.S.A.

No parts of the content (including logos, design, photos, text, colour scheme arrangements, etc.) may be reproduced, reused or redistributed for any purpose whatsoever, or distributed to a thirdparty for such purposes, without the written permission of The dyras wwe.factory LLC.

®= registered trademark of Dyras Europe Kft.