

Használati útmutató


dyras

Vezeték nélküli telefontöltő
Modell: AUD-CH3001G



Kérjük, használat előtt figyelmesen olvassa el a használati útmutatót!

A VEZETÉK NÉLKÜLI TÖLTŐ FELÉPÍTÉSE



A DOBOZ TARTALMA

1. AUD-CH3001G vezeték nélküli telefontöltő
2. USB-C – USB töltőkábel
3. Használati útmutató

TECHNIKAI ADATOK ÉS TERMÉKJELLEMZŐK

| |
|--|
| Bemenet: 12V/1,67A; 9V/1,67A; 5V/2A |
| Kimenet: 15W (kompatibilis: 10W, 7,5W és 5W) |
| Töltésátvitel: 72% (max.) |
| Méret: átmérő 100mm, vastagság 7mm |
| Anyaga: cink ötvözet + textil |
| Kompatibilis: Qi típusú gyorsöltésre alkalmas telefonokkal |
| Intelligens fémfelismerés |
| Praktikus, ultravékony kialakítás |
| Hordozható |



A TERMÉK HASZNÁLATA

1. Első lépés:
 - a. Normál töltési funkció: Csatlakoztassa a vezeték nélküli töltőt a mellékelt kábel segítségével a számítógép USB portjához!
 - b. Gyorstöltés megvalósításához használjon QC 3.0 / QC 2.0 típusú hálózati gyorstöltőt! Dugja be a fali konnektorba a hálózati gyorstöltőt, majd kábel segítségével csatlakoztassa a kerek, vezeték nélküli töltőhöz!
2. A LED fény pirosan világít, amikor csatlakoztatja.
3. Győződjön meg róla, hogy ne legyenek kábelek vagy egyéb tárgyak a töltő felületén ill. közvetlen közelében!
4. Helyezze rá a mobilelefont a töltőfelületre!
5. Töltés közben kék LED fény világít. Ha a telefon feltöltődött, a fény kikapcsol.
6. Túlmelegedés esetén távolítsa el a készüléket a felületről és várja meg míg a vezeték nélküli töltő visszahűl! Ezután újra használható.

FIGYELEM!

1. Kérjük, ne húzza a kábelt erővel!
2. Kérjük, ne szedje szét a terméket!
3. Kérjük, ne helyezze a terméket hőforrások közelébe!
4. Kérjük, ne helyezze a terméket víz közelébe, vízbe vagy nedves helyre!
5. Kisgyermekektől tartsa távol!
6. A termék telefontöltésre szolgál. Kérjük ne használja más célokra!

HULLADÉKKEZELÉS

| Használt elektromos és elektronikus berendezések megsemmisítése | |
|---|--|
|  | <p>Ez a jelzés a terméken és a csomagoláson azt jelzi, hogy tilos háztartási hulladék közé dobni a már nem használt terméket, mivel kifejezetten környezetszennyező. További részletekkel kapcsolatban érdeklődjön a helyi hatóságnál!</p> |
|  | <p>Ez a jelzés az Európai Unió teljes területére érvényes. Amennyiben az Európai Unión kívül szeretné megsemmisíteni a terméket, érdeklődjön az ezzel kapcsolatos szabályzásokról a helyi hatóságnál!</p> |

Gyártó/Importőr: Vöröskő Kft., 8200 Veszprém, Pápai út 36.

A CE SZIMBÓLUM



A jelölés azt hivatott jelezni, hogy a termék a rá vonatkozó Európai Uniós előírásoknak megfelel és szabadon forgalmazható az Európai Unió területén.

Instruction Manual


dyras

Wireless mobile phone charger
Model: AUD-CH3001G



Please carefully read the instructions before using!

PARTS OF THE WIRELESS CHARGER



CONTENT OF THE BOX

1. AUD-CH3001G wireless charger
2. USB-C – USB cable
3. Instruction manual

SPECIFICATION AND FEATURES

| |
|--|
| Input: 12V/1,67A; 9V/1,67A; 5V/2A |
| Output: 15W (compatible with 10W, 7,5W and 5W) |
| Charge conversion: 72% (max.) |
| Size: diameter 100mm, width 7mm |
| Material: zinc alloy + textile fabric |
| Compatible with Qi type fast charging phones |
| Intelligent identification of metal |
| Practical, ultra-thin design |
| Portable |

USING THE APPLIANCE

1. First step:
 - a. For normal charging function: connect the wireless charger - with the attached cable - to the USB port of your computer.
 - b. For quick charging function, use a QC 3.0 / QC 2.0 travel charger. Put the travel charger into the wall socket, then connect it to the rounded wireless charger with cable.
2. The LED lights up red when connected.
3. Make sure there are no cables or any other objects on the top of the wireless charger and nearby!
4. Place your phone on the charging surface.
5. During charging, the blue LED lights up. When the phone is charged, the light turns off.
6. If the wireless charger is overheating, remove the phone from the surface and wait for the wireless charger cooling down before using it again!

WARNING!

7. Please do not pull the cable with force!
8. Please do not disassemble the product yourself!
9. Please do not place this product near heat sources!
10. Please do not place the product close to water, into water or in damp places.
11. Keep it far from babies and small children!
12. The product is designed for mobile phone charging. Do not use it for any other purpose!

WASTE MANAGEMENT

Correct Disposal of this product



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.

Manufacturer/Importer: Vöröskő Kft., 8200 Veszprém, Pápai str. 36.

CE SYMBOL



The mark is intended to indicate that the product complies with the relevant European Union standards and can be freely marketed in the European Union.

dyras

www.dyras.hu

Copyright © 2021 The dyras wwe.factory LLC U.S.A.

No parts of the content (including logos, design, photos, text, colour scheme arrangements, etc.) may be reproduced, resued or redistributed for any purpose whatsoever, or distributed to a thirdparty for such purposes, without the written permission of The dyras wwe.factory LLC.

®= registered trademark of Dyras Europe Kft.