

Használati útmutató

dyras

Álló ventilátor
Modell: SF-2002



Kérjük, használat előtt figyelmesen olvassa el a használati útmutatót!


BIZTONSÁGI UTASÍTÁSOK

1. Ellenőrizze az adattáblán feltüntetett feszültséget! Ezt az eszközt 220–240 V-os elektromos áramellátásra tervezték.
2. Ne javítsa a készüléket saját maga, hibás készüléket csak a szerviz javíthatja!
3. Ne működtesse a készüléket nedves kézzel!
4. Ha a tápkábel megsérül, a veszély elkerülése érdekében a gyártónak, annak szervizképviselőének vagy hasonlóan képzett szakembernek kell kicserélnie!
5. Amikor a készüléket nem használja, kapcsolja ki és húzza ki a konnektorból!
6. A sérülések elkerülése érdekében ne helyezzen dolgokat a levegő ki- és bemeneti nyílásokba!
7. Ne használja a készüléket robbanásveszélyes és éghető gázok közelében!
8. A készüléket csak sík felületen használja!
9. Ne használja a szabadban!
10. Ne döntse fel a készüléket! Húzza ki a tápegységet, ha felborul és víz van a testben! Újboli használat előtt szárítsa meg a testet.
11. Tisztítsa meg a külső felületet enyhén nedves ruhával. Semleges tisztítószerekkel is tisztítható. Ne öblítse le vízzel.
12. Használat közben ne ütögesse vagy rázza a testet, különben leállást okozhat!
13. Ne használja a készüléket fürdő, zuhanyzó vagy úszómedence közvetlen közelében!
14. Ezt a készüléket azok a személyek, akik csökkent fizikai, érzékelési vagy szellemi képességekkel rendelkeznek, vagy akiknek a tapasztalata és a tudása hiányzik, továbbá gyermekek 8 éves kortól csak abban az esetben használhatják, ha az felügyelet mellett történik, vagy a készülék használatára vonatkozó útmutatást kapnak, és megértik a használatból eredő veszélyeket.
15. A gyermekek nem játszhatnak a készülékkel! A gyermekek nem végezhetnek tisztítást és karbantartást felügyelet nélkül!
16. A távirányító CR2025 gombellel működik.

SPECIFIKÁCIÓ

Teljesítmény	50 W
Magasság	88 cm
Tömege	2,6 kg
Névleges lapát átmérő	20 cm
Tápkábel hossza	1,6 m
Kijelző	LED
Irányítás	távirányító, érintógombos kijelző

A KÉSZÜLÉK HASZNÁLATA





A készülék használatának megkezdéséhez először helyezze a ventilátort szilárd vízszintes helyre és csatlakoztassa a hálózati csatlakozót a megfelelő aljzatba.


Kicsomagolás után ellenőrizze, hogy a termék jó állapotban van-e és nincsen semmi felületi hiba.


Először távolítsa el a csavart a cső alján, helyezze be az összekötő csövet a talpba és rögzítse a csavarral.


Lazítsa meg a hátul lévő rögzített csavart a vezérlőegységen és helyezze a ventilátor fejet a csatlakozóra. Húzza meg a rögzítőcsavart a fej rögzítéséhez.




Kapcsolja az  ON / OFF gombot a készülék kijelzőjén vagy a távirányítón a ventilátor be/kikapcsolásához.

Nyomja meg a  SPEED gombot a ventilátor sebességének módosításához. 3 sebességi fokozat állítható.


3 féle szellőzési mód állítható (csak távirányítóval!) a  „Wind” gomb nyomásával, Normál – Természetes szél – Éjszakai szellőzés
Természetes és Éjszakai módban szellőkéseket imitál a készülék.

Nyomja meg a  „OSC” gombot az automatikus oszcilálás be/kikapcsolásához.

A ventilátor fej pozíciója manuálisan 90°ban állítható vertikálisan.

Nyomja meg a  „TIMER” gombot az időzítő beállításához. 1-15 óra beállítható.

A készülék kijelzője 60s után automatikusan alvó üzemmódba kapcsol.





TISZTÍTÁS ÉS KARBANTARTÁS

A készülék tisztítása előtt kapcsolja ki és húzza ki a konnektorból!
Puha ruhával tisztítsa meg a készülék felületét, és puha sörtés kefével távolítsa el a port a levegő be- és kimeneti nyílás rácsaiból.

Figyelem! Víz nem érheti a készülék kijelzőjét!

HULLADÉKKEZELÉS

Használt elektromos és elektronikus berendezések megsemmisítése	
 	<p>Ez a jelzés a terméken és a csomagoláson azt jelzi, hogy tilos háztartási hulladék közé dobni a már nem használt terméket, mivel kifejezetten környezetszennyező. További részletekkel kapcsolatban érdeklődjön a helyi hatóságnál!</p> <p>Ez a jelzés az Európai Unió teljes területére érvényes. Amennyiben az Európai Unióon kívül szeretné megsemmisíteni a terméket, érdeklődjön az ezzel kapcsolatos szabályzásokról a helyi hatóságnál!</p>

Gyártó/Importőr: Vöröskő Kft., 8200 Veszprém, Pápai út 36.

A CE SZIMBÓLUM



A jelölés azt hivatott jelezni, hogy a termék a rá vonatkozó Európai Unió előírásoknak megfelel és szabadon forgalmazható az Európai Unió területén.

dyras

Instruction Manual

dyras

Stand fan
Model: SF-2002



Please read the instructions carefully before using!


GENERAL SAFE GUARDS

1. Use as per the rating voltage.
2. Do not repair or remake the appliance by yourself, it should be repaired by the repairmen.
3. Do not operate the appliance with wet hands, in order to avoid damage.
4. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
5. When the appliance is not in use, switch it off and unplug it.
6. Do not insert things to air outlets and inlets, in order to avoid damage.
7. Do not use the appliance near explosive and combustible gas.
8. Use the appliance only on a flat surface.
9. Do not use outdoors.
10. Do not turnover the appliance. Unplug the power supply If it is toppled over and there have some water in the body. Dry the body before use.
11. Clean the appearance with a lightly damp cloth. It can clean with neutral detergents. Do not rinse with water.
12. Do not knock or shake the body when use, otherwise it may cause stop.
13. Do not use the appliance in the immediate surrounding of a bath, a shower or a swimming pool.
14. This appliance is not intended for use by persons including children with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
15. Children should be supervised to ensure that they do not play with the appliance.

SPECIFICATION


Power	50 W
Height	88 cm
Weight	2,6 kg
Nominal blade diameter	20 cm
Power cable length	1,6 m
Screen	LED
Control	remote control, digital display

USING THE APPLIANCE



After unpacking, check whether the body is in good condition and whether there is any defect.

First remove the screw at the bottom of the connecting pipe, insert the connecting pipe into the chassis and fix it together with the screw. Loosen the fixed screw at the back of the control box, put the machine head on the connecting pipe, and tighten the fixing screw to fix the machine head and the connecting pipe together.



Plug in first.

Put the plug into the socket, products in standby, power indicating light is on.

ON/OFF button: Push "ON/OFF" button to working state, push it again to standby.

SPEED button: Push "SPEED" button to set from HIGH-MIDDLE-LOW fan speed.


WIND button(on the remote control only): Push "WIND" button to set from Normal wind- natural wind-sleeping wind.

OSCILLATION button: Push "SWING" button to oscillate the fan, push it again to stop the function.

Can manually adjust the range of 90 degrees vertically and 70 degrees horizontally

TIMER button: Push "TIMER" button from 00-15 hours.

After 60 seconds automatically turn off the screen



CLEANING AND MAINTENENCE

Clean with neutral detergent and soft cloth. Attention: unplug the power plug when clean the appliance, since there have high pressure in the body.

Do not leave any water on the control panel.

WASTE MANAGEMENT

Correct Disposal of this product



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Manufacturer/Importer: Vöröskő kft., 8200 Veszprém, Pápai út 36.

CE SYMBOL



The mark is intended to indicate that the product complies with the relevant European Union standards and can be freely marketed in the European Union.

dyras

www.dyras.hu

Copyright © 2022 The dyras wwe.factory LLC U.S.A.

No parts of the content (including logos, design, photos, text, colour scheme arrangements, etc.) may be reproduced, resued or redistrubuted for any purpose whatsoever, or distributed to a thirdparty for such purposes, without the written permission of The dyras wwe.factory LLC.

®= registered trademark of Dyras Europe Kft.