

Használati útmutató

dyras

**Hálózati gyorsító mobiltelefonhoz
Modell: CDA-68W**



Kérjük, használat előtt figyelmesen olvassa el a használati útmutatót!

A DOBOZ TARTALMA

1. CDA-68W hálózati gyorsító
2. Használati útmutató

SPECIFIKÁCIÓ

Kompatibilis minden gyorsító funkció, type c csatlakozós eszközzel
PD 20W
Type-C töltés
USB-C
Bemenet: AC100-240V 50/60Hz
Kimenet: Type-C: 20W
Burkolat anyaga: műanyag



A KÉSZÜLÉK HASZNÁLATA

1. Ügyeljen arra, hogy az összes csomagolóanyagot eltávolítsa!
2. Dugja be a töltőt a konnektorba!
3. Csatlakoztasson egy kompatibilis töltőkábelt (Type-C típus) a töltő USB C kimeneti portjára!
4. A kábel másik végét csatlakoztassa a feltöltendő eszközhöz!
5. A töltés végeztével húzza ki a töltőt a konnektorból!

FIGYELEM!

1. Kérjük, ne szedje szét a terméket!
2. Kérjük, ne helyezze a terméket hőforrások közelébe!
3. Kérjük, ne helyezze a terméket víz közelébe, vízbe vagy nedves helyre!
4. Kisgyermekektől tartsa távol!
5. A termék eszközök töltésére szolgál. Kérjük ne használja más célokra!

HULLADÉKKEZELÉS

Használt elektromos és elektronikus berendezések megsemmisítése	
 	<p>Ez a jelzés a terméken és a csomagoláson azt jelzi, hogy tilos háztartási hulladék közé dobni a már nem használt terméket, mivel kifejezetten környezetszennyező. További részletekkel kapcsolatban érdeklődjön a helyi hatóságnál!</p> <p>Ez a jelzés az Európai Unió teljes területére érvényes. Amennyiben az Európai Unióon kívül szeretné megsemmisíteni a terméket, érdeklődjön az ezzel kapcsolatos szabályzásokról a helyi hatóságnál!</p>

Gyártó/Importőr: Vöröskő Kft., 8200 Veszprém, Pápai út 36.

A CE SZIMBÓLUM



A jelölés azt hivatott jelezni, hogy a termék a rá vonatkozó Európai Uniói előírásoknak megfelel és szabadon forgalmazható az Európai Unió területén.

Instruction Manual

dyras

**Quick charger for mobile phone
Model: CDA-68W**



Please carefully read the instructions before using!

CONTENT OF THE BOX

1. CDA-68W quick charger
2. Instruction manual

SPECIFICATION

Compatible with all devices that support quick charging function Type C
PD 20W
Type-C power
USB-C
Input: AC100-240V 50/60Hz
Output: 20W
Housing material: plastic

USING THE APPLIANCE

1. Be sure to remove all packing materials!
2. Connect the charger to the power socket!
3. Connect a compatible cable (Type C) to the USB-C port of the charger!
4. Connect the other end of the cable to the device that you want to charge!
5. When charging is complete, unplug the charger from the power socket!

WARNING!

1. Please do not disassemble the product yourself!
2. Please do not place this product near heat sources!
3. Please do not place the product close to water, into water or in damp places!
4. Keep it far from babies and small children!
5. The charger is designed for device charging. Do not use it for any other purpose!

WASTE MANAGEMENT

Correct Disposal of this product



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Manufacturer/Importer: Vöröskő Kft., 8200 Veszprém, Pápai str. 36.

CE SYMBOL



The mark is intended to indicate that the product complies with the relevant European Union standards and can be freely marketed in the European Union.

dyras

www.dyras.hu

Copyright © 2021 The dyras wwe.factory LLC U.S.A.

No parts of the content (including logos, design, photos, text, colour scheme arrangements, etc.) may be reproduced, reused or redistributed for any purpose whatsoever, or distributed to a thirdparty for such purposes, without the written permission of The dyras wwe.factory LLC.

®= registered trademark of Dyras Europe Kft.